


A710-26

MASSAGE CHAIR

SAVE THESE INSTRUCTIONS



————— Operation Instructions —————

Thanks for purchasing this product. Please read this manual instruction carefully in order to know how to use this product correctly before operation. Please pay more attention to some important safety warning and keep this manual book properly for future use.

Note: Our company reserves the right to change and explain the design of the product. If there is some difference between the product function in market circulation and the description in the manual, it is a normal update of the product, and our company will not inform you otherwise. The specific product function and color shall prevail in kind.

CONTENTS

Before use

Safety precautions	02-05
Installation parts	06-07
Place massage chair	08-09
Before use	10-11
Product structure	12-18

Usage method

Operation Instructions	19-62
End massage	62

Maintain



Cleaning and Maintenance	63
--------------------------	----

Important


Troubleshooting	64
Product Specifications	65

Safety Precautions (Must be observed)


- Please read all relevant instructions carefully before use.
- The notes marked here will help you to use the product safely and correctly.
- In order to clearly indicate the extent of harm and damage, precautions are divided into **"Warning"** and **"Caution"** that may be caused by incorrect use. Both of them are important for safety and must be followed.

 Warning	Indicates that serious injury or death may result from improper use.
 Caution	Indicates that misuse may cause minor injury or property damage.


- Please pay attention to the symbol before each safety item.


 Forbidden	Absolute prohibition
--	----------------------

The following populations should not use this product

 Forbidden	<ul style="list-style-type: none"> ■ The device is not intended for use by persons (including children) with physical disabilities, sensory or neurological impairments or who lack experience and common sense, unless they are supervised and instructed in the use of the device by those responsible for their safety. Children must be supervised to ensure they do not use tools for play. ■ Patients with osteoporosis. ■ Patients with severe heart disease and wearing implantable medical devices such as pacemakers and defibrillators that are susceptible to electromagnetic waves. ■ People who have a fever (above 38 degrees). ■ Pregnant women or shortly after childbirth and during their menstruation period. ■ People who follow medical advice and are prohibited from receiving massage due to thrombosis, aneurysm, severe varicose veins, or other circulatory diseases. Within two weeks after the appearance of blood clots, it is strictly prohibited to massage any form of body parts that have blood clots. ■ Patients who are injured or have a skin disease. ■ When unsupervised, any children are under the age of 14 and those unconscious are not allowed to use this product. ■ People who require rest or feel unwell as instructed by a doctor. ■ People with spinal abnormalities or scoliosis are prohibited from receiving this product due to medical advice due to other diseases. ■ People whose bodies are wet are forbidden to use this product. ■ This product has a hot surface. Persons insensitive to heat must pay attention when using this product.
---	--

Safety Precautions (Must be observed)

Important safety warnings	
 Warnings	<ul style="list-style-type: none"> ■ Keep children away from the movable parts of this product. ■ Use the well-grounded power supply unit suitable for this product. ■ Pull out the plug after use or before cleaning to avoid any damage to physical injury or the product. ■ Operate this product as instructed in this manual. ■ Do not use any parts or accessories which are not recommended. ■ Do not use this product outdoors. ■ Do not use near open flames such as stoves, and do not smoke while using. ■ Do not use heating equipment such as electric blankets on this product. ■ Do not sit on the back of the chair, leg massagers, shoulders, armrests, or stand on the seat. ■ Please read the Operation Instructions carefully before operation. ■ Never use this product for any other purpose not listed in the manual . ■ 20 minutes of usage each time is recommended. ■ Do not use this product if the cover or leather is broken or damaged. ■ Do not drop anything into this product. ■ Never fall asleep while using this product. ■ Do not use this product if you are drunk or feel unwell. ■ Do not use this product within one hour after a meal. ■ Do not use this product with excessive force to avoid any injury. ■ Do not use for purposes other than massage. ■ If the supply cord is damaged, to avoid danger, it must be replaced by a professional from the manufacturer, its maintenance department or similar department

Operating environment	
 Caution	<ul style="list-style-type: none"> ■ Do not use this product in a very moist environment such as the bathroom. ■ Stop using this product immediately when the ambient temperature changes sharply. ■ Do not use this product in any heavily-dusty or caustic environment. ■ Do not use this product in a small space or a place without good ventilation.

Safety Precautions (Must be observed)

Storage conditions



Caution

- Storage room temperature: 5 °C to 40 °C.
- Relative humidity (RH) between 20% and 80%; free of corrosive gases, and a well-ventilated room.

Product service and maintenance



Caution

- This product should be maintained by the service center designated by the manufacturer only. No user should disassemble or maintain it without permission.
- Do not forget to turn off the main power switch after usage.
- Do not use this product if the power socket becomes loose.
- If this product will be left unused for a long period of time, it is necessary to roll up the power cord of this product and store this product in a dry and dust-free environment.
- Do not store this product at a high temperature or near open flame. Avoid prolonged exposure to direct sunshine.
- Please clean this product with dry cloth. Never use thinner, benzene or alcohol.
- The mechanical components of this product are specially designed and manufactured, so no special maintenance is needed.
- Do not use a sharp object to stab at this product.
- Do not roll or pull this product on any uneven ground. Instead, it should be lifted before moving.
- Please use this product intermittently. Do not keep it working continuously for a long period of time.

Solutions to ordinary malfunctions



Caution

- If the motor sounds during operation of this product, this is the normal operation sound.
- If the controller cannot work normally, check whether the plug and the power socket are connected reliably, and whether the power switch is turned on.
- If the rated working time is over, this product will automatically activate the power-off button; If this product keeps operating for a long period of time, the temperature protector will stop this product automatically. The product can be used again after half an hour.

Safety Precautions (Must be observed)

Safety precautions





Caution

- Check whether voltage is consistent with the specification of this product.
- Never insert or pull out the plug with a wet hand.
- Do not let water flow into this product to avoid electric shock or cause damage to this product.
- Do not pull the power cord when plugging or unplugging it. Rough handling is forbidden.
- Do not damage the wire or modify the circuit of this product.
- Do not clean live parts of this product with a wet cloth such as a power switch and plug.
- Be away from this product in case of power failure to avoid any injury if power is restored suddenly.
- Stop using this product at once while it works abnormal, and consult your local supplier.
- Stop using this product if you feel unwell, and consult your health care practitioner.



Installation parts

Installation Instructions for Armrests



1. Find out the connector and air tube from the bottom of the seat frame and pass out from the middle of the seat frame (Figure 1).
2. Take out the armrest from the package and make the connector and air tube on the armrest correspond to the connector and air tube at the bottom of the seat frame one by one (butt joint according to the mark on the physical butt joint line) (Figure 2).



3. The connector and air tube on the armrest are inserted into the connector and air tube at the bottom of the seat frame, which should be in place and firm (Figure 3).
4. After the air tube and connector are docked, insert them into the bottom of the seat frame and take care to avoid the air tube from being folded (Figure 4).





5. Hold the armrest with both hands, first hook the front end of the armrest, hang it in the seat frame steel and press down the front end of the armrest. (Figure 5)
6. Then, align the male buckle on the rear end of the armrest with the female buckle on the capsule, insert the rear end of the armrest into the female buckle of the capsule and snap it tightly (note that the fit gap of the armrest capsule should be even). (Figure 6)





Installation parts

7. Fix the rear end of the armrest tightly with a M6*20 screw (Figure 7).
8. Pull the upper arm holster away and fix it with a M6*20 screw (Figure 8);





9. Align the mounting holes that fix the steel frame at the front end of the armrest, and then use the provided 4# Allen wrench to fix and tighten the armrest and the seat frame steel piece with two M5*14 black zinc environmental friendly hexagon socket head cap screws and a 6*12*1.5 black zinc environmental friendly flat pad (Figure 9).
10. Install the screw hole plug at the back end of armrest (Figure 10).





Installation Instructions for Legrest

1. First of all, cut the connection wire and the air pipe tie fixed on the steel pipe (Figure 1).
2. Connect the connection wire and the air pipe leading from the lower end of the backrest to the legrest connectors. Confirm whether butt connection is OK. Then insert the butt connection wire and air pipe into the bottom of the frame from the lower hole of the backrest. Pay attention to avoiding any air pipe bending during insertion (Figure 2).





Installation parts


3. Firstly, insert the rotating inner sleeve and the rotating outer sleeve into the left and right rotation shafts of the legrest (Note: The large step must face inward) (Figure 3).
4. Then remove the rotation shaft cover supporting the legrest on the left and right frames of the massage chair (Figure 4).



5. Next, hang the legrest (left and right rotation shafts) into the rotation shaft cover supporting such frames simultaneously (Figure 5).
6. Place the rotation shaft cover. Press the rotating outer sleeve of the legrest. Then tighten the rotation shaft cover supporting the legrest with two M5×14 black zinc environmentally-friendly hexagonal socket head screws and a 6×12×1.5 black zinc environmentally-friendly flat pad by the supplied 4# hex wrench (Figure 6).





7. After the screws are tightened, hook the groove at the back end of the legrest cover to the hinge pin. Then press down the front end of the legrest cover to make it completely parallel to the rotation shaft cover. Hook the convex point at the side of the legrest cover to the hole at the side of the legrest hook. Finally, the legrest is installed (Figure 7)



Installation parts

Installation Instructions for Legrest

1. Align the positioning column of the bracket assembly with the positioning hole of the armrest bracket support plate and lock it with 3 cross-recessed screws (Figure 1).
2. Then fasten the decorative cover of the support (Figure 2).




Place massage chair

Installation placement

Make sure there is enough space for the massage chair can be tilted at least 2.5 cm.



Do not expose the massage chair directly to high temperature environment due to sunlight (such as: in front of heating equipment), and place it to where can avoid high temperature and direct sunlight. It is recommended to lay a soft cushion for long-term use in a designated location. When laying the cushion, the size of the cushion should be enough to cover Keep the range where the machine touches the floor and the range where your feet touch the floor.




Product lift instruction

Require team work to lift and move the chair to avoid injury.



1. Please lift the massage chair to move it on vulnerable ground such as wooden floor.
2. When moving on a similar wooden floor, it is recommended to lift it. Avoid damage to the casters. When the floor is lifted and moved to the designated position, be careful to keep your hands out of the way to avoid injury, and be careful of your feet being crushed. Do not let go of the unit until the unit is completely flat, the floor may be damaged, therefore, it is recommended to place mats, etc. on the floor.



Place massage chair


Move method

Use the rear casters to move the massage chair. Move the chair by tilting it down and backward about 45° as shown in the diagram.





NOTE: Excessive force to title will cause the chair to tip over completely and product damage.

1. Before moving, please shut down the machine properly to reset the whole machine, and then cut off the power.
2. Please keep the chair vacant when moving. (People, pets or clutter will not be able to stay on the chair.)
3. When moving, do not cross a drop barrier higher than 2mm or a gap greater than 5mm.
4. When using casters to move this product, single continuous movement is not supported; if the distance exceeds 50 meters, please make this product move slowly and evenly.



How to disassemble and use headrest cushion and backrest cushion


Using a headrest cushion can reduce the intensity of kneading massage on the neck and shoulders, and you can decide whether to use a headrest cushion according to your needs (recommended to use a headrest cushion). The backrest cushion and the backrest are connected by a zipper (1), and the headrest cushion and the backrest cushion are connected by a zipper (2).



Before use

Check around

Make sure that there are no people, pets and other objects around the unit.




Make sure there are no foreign objects in the gaps of the machine

Before massaging, make sure that no foreign objects are caught in the legs, feet, etc.


Under no circumstances allow hands, feet, and head to penetrate into the area between the lower leg mechanism and main body, or the area between the armrest and the capsule.

Under no circumstances should hands, feet, or head sink under the fabric or leather covering of the massage area.




Before use


Turn on the power



1 Plug in power cord



2 Schematic diagram of power on




3 Turn on the power switch ("I" position)



- Please check the power cord and plug for damage before use.
- Please supply power to this product in accordance with the working power requirements of this product's calibration.
- It is strictly forbidden to use a power supply other than the nominal power supply of this product.
- It is strictly forbidden to connect various power conversion devices without authorization to supply power to this product.

Product structure

Description of Components




- | | |
|--------------------------|-----------------------|
| 1.Small head cushion | 7.Large head cushion |
| 2.Shoulder pressure | 8.Shawl |
| 3.Hand controller | 9.Shortcut keys |
| 4.Hand controller holder | 10.Armrest |
| 5.Backrest cushion | 11.Armrest mood light |
| 6.Leg mechanism | 12.Side cover |
| • Massage | |

★Other configuration functions

- Bluetooth APP function
- Smart device Bluetooth APP operating system
- WIFI function

Product structure

Schematic view of functional distribution




- | | |
|---|--|
| 1.Shoulder | 5.On both sides of the head |
| • Airbag massage | • Digital audio system |
| 2.Arms | • Music playback |
| • Health sensors | • Voice control function |
| • Hand controller holder | • Built in voice controlled microphone |
| • Wireless charging | • Negative ion generator |
| 3.Palm | 6.Head and neck to seat |
| • Airbag massage | • Back mechanism massage |
| • Convex point massage and magnetic therapy | 7.Waist and abdomen |
| 4.Footrest | • Shoulder and back |
| • Air pressure massage | • Shawl heating function |
| • Roller massage | 8.Legs |
| • Ankle stretching | • Airbag massage |
| • Ankle bump massage | • Kneading function |
| • Electric leg extension adjustment | • Leg traction |
| • Automatic detection of foot length | • Calf roller massage |

Product structure


How to use the shawl

It features a unique shawl component, with innovative heating functions on the shoulder, back, waist and abdomen. Users can place the shawl at different massage positions according to massage requirements.



Schematic diagram of use on back and waist


When the shawl component is placed on the back and waist position, the shawl built-in heating, dredge the back meridians, promote blood circulation and warm the kidney, relieve low back pain, back cold stiffness, pain and other conditions.



Product structure

Schematic diagram of use on shoulder and abdomen

When the shawl component is placed at the shoulder position (front/rear), it will heat the acupoints such as Bingfeng, Tianzong, Yunmen and Qihu around the shoulder and clavicle through the shawl built-in heating; it can also be placed on the abdomen to heat the abdomen through the shawl built-in heating.





Use demonstration of the shawl on the back




Caution

1. Correct placement and use: When the shawl is used on the back (or the massage chair is not turned on), please place the shawl on both sides of the backrest and put the lower magnet and the backrest cushion lumbar position of the magnet corresponding suction well; if you do not need to use the shawl function, level the shawl and lift back behind the massage chair.
2. Wrong placement and use: When the shawl is used on the back (or the massage chair is not turned on), do not bring the shawl together in the middle manipulator massage area, which may lead to functional failure, product failure and other serious faults. At the same time, do not fold, twist, cross the shawl, and place and use the shawl on your back.




Product structure

Remote controller keys instruction



- 01.On/off touch key: Turn on or off the massage chair function.
- 02.Pause key: Turn on or off the back heating function.
- 03.Back heating key: Enable or disable the Back Heating function.
- 04.O2-Ion key: Turn on or off the negative oxygen ion function.
- 05.Sole roller key: Turn on or off the sole roller function.
- 06.Calf kneading key: Turn on or off the calf kneading function.
- 07.Voice control key: Wake up voice assistant.
- 08.Intensity selection key: Select one from different automatic massage intensities.
- 09.Volume adjustment key: Adjust the volume level of the controller.
- 10.Sensor: Human health detection sensor.
- 11.ON/OFF key: Turn on or off the massage chair.
- 12.Lower body air pressure intensity key: Adjust the air pressure.
- 13.Massage area key: The function of selecting massage position.
- 14.Shoulder position adjustment key: Adjust the shoulder position, confirm the massage position.
- 15.Current status key: Enter to view current massage chair status.
- 16.Auto key: Enter the automatic massage program selection function.
- 17.Manual key: Enter the manual setting massage function.
- 18.Angle key: Enter the angle adjustment interface to select the sitting posture angle.
- 19.Settings key: Enter the setting menu interface.


Product structure



- 20.Massage technique selection key: Select the massage technique.
- 21.Upper body air pressure intensity key: Adjust the air pressure.
- 22.Status display bar key: Display the massage program status information.
- 23.Air massage selection key: Select air position.
- 24.Time adjustment menu key: Adjust the massage time.
- 25.Massage speed key: Adjust the massage speed.
- 26.4D intensity key: Adjust 4D intensity.
- 27.Health detection key: Enter the health detection interface.
- 28.Custom key: Enter the custom interface.
- 29.Storage key: Enter the storage interface

Product structure


Description of armrest shortcut keys



1. 4D Intensity rotation key: Adjust the massage intensity of the 4D back mechanism.
2. On/Off key: Turn on (short press to pause) or off the massage chair.
3. Zero Gravity key: Adjust massage chair to the zero gravity angle.
4. Footrest extension key: Extend the foot rest by adjustment.
5. Footrest shortening key: Shorten the foot rest by adjustment.
6. Wireless Charging key: Mobile Phone Wireless Charger.
7. Auto key: Adjust the automatic massage function, and cyclically switch the automatic function every time you press it.
8. Voice Control Wake-up key: Short press this key to wake up the voice control, long press for 3 seconds to turn on/off the voice control function.
9. Linkage Lying key: Adjust the linkage lying angle.
10. Linkage Up key: Adjust the linkage up angle.


Operation Instructions

I.Start massage

1. Press the remote controller side button on/off key  or long press the armrest on/off key
2. After the start-up screen, the brand logo animation will be displayed, automatically entering the warning interface. Then, click the "Tap here to confirm" key to enter the massage selection intensity interface.

Warning


1. Medical warnings:
 - Individuals suffering from osteoporosis, spine fracture, sprain, or acute pain such as a pulled or torn muscle should not use the product. • Individuals who have a pacemaker, defibrillator, or other personal medical devices prone to electronic interference should not use the product.
 - Pregnant women and women who have just given birth should not use the product.
 - Individuals with symptoms of acute low back pain, herniated disk, spondylolisthesis, spinal stenosis, degenerative lumbar spondylosis should not use the product.
 - Individuals who have abnormalities or curvature of the spine should not use the product.
 - Children under 14 years of age should not use the product. Please refer to the instruction manual for other individuals who are not suitable for massage.
2. Emergency Stop In case of emergency, press the stop button on the remote to stop the operation
3. The areas under the footrest and behind the back rest are potentially dangerous for a child or pet. To avoid serious injury or death, keep children and pet away from the chair while in use and check these areas carefully before reclining, lowering legrest, or returning chair to upright position.




Tap here to confirm

Operation Instructions

3. After the system is started, select the massage intensity by clicking on any one of the Gentle, Soothing or Strong keys on the remote controller to turn on the massage chair and enter the lying state. If it is not selected within 5 minutes, the massage chair will turn off automatically.




4. For automatic angular adjustment, select the automatic program, then the massage chair will be automatically adjusted to zero-gravity angle, and wait until its adjustment is completed. To skip a step, press the skip key **Skip** to go directly to the next step.




Operation Instructions


5. Wait until body shape detection is completed, or you can press the skip key **Skip** to skip detection and start massage directly.



6. For fine adjustment of shoulder position, after body shape detection, the remote controller or a voice prompt will remind the user of fine adjustment of shoulder position. If the massage roller stops at the shoulder position, directly press the OK key **OK** to start massage. If not, use the Up key **▲** and Down key **▼** to adjust the massage roller to the shoulder position, and then press the OK key **OK** to start the massage. If no operation is made within 20s, directly default the current massage roller position for the shoulder position and start massage.




Operation Instructions



II. Pause function (please use this function after the equipment is turned on)

After the massage chair is turned on, press the pause key to enter the pause state, then all massage functions will be suspended, and press the pause key again to resume the previous massage state. Note: In the pause state, all functions do not work except shutdown. If Pause more than 20 minutes, will shutdown reset automatic




Operation Instructions

III. Automatic program (please use this function after the equipment is turned on)

1. Automatic program: As shown in the figure below, click the "Auto" key in the left menu bar. After entering the automatic function interface, select the corresponding automatic program for massage according to the massage needs.

(1). In the automatic program selection interface, there are four automatic massage scenes and one "online program" automatic recommendation program. There are 20 automatic program options available: Stress Relieving, Neck & Shoulder Care, Back Spa, Hips&legs Fit, Leg&foot Relieve, Energy, Lunch Break, Sweet Dream, Relieve Muscle, Body Balance, President Cosy, Keep Fit, Superior Enjoyable, Office Regimen, Health Recharge, Yoga massage, Chinese Massage, Full-body stretch, Spine Traction, Spine Massage

(1). Select and click the desired automatic massage program and click to start massage.



Schematic diagram of automatic massage program selection

Massage scenes(AI Intelligent)	
Function	Description
Stress Relieving	Restore the full body from fatigue and pain; achieve relaxation, improve micro-circulation, and quickly relieve fatigue for the back and limbs.
Neck & Shoulder Care	Massage the neck and shoulders by means of kneading and stretching techniques mainly, and also the upper back by medical massage, and then press the Jianjing acupoint to relieve cervical spondylosis and achieve the effect of relaxing the muscles of the neck and shoulders. Massage intensity is gentle, suitable for people working in office and suffering from cervical fatigue.

Operation Instructions

Back Spa	Mainly use anti-kneading, positive and negative kneading techniques to do back-opening massage on the entire back, combined with flapping and shiatsu techniques, the massage intensity is moderate, suitable for people with back congestion and poor blood flow.
Hips&legs Fit	Massage buttocks by kneading and medical massage mainly, and then through patting and kneading, deeply massage buttocks and perineum, to relax the hip muscles and lift the hip, which is suitable for women massage, and also for men for maintenance of prostate.
Leg&foot Relieve	Massage the shoulders and waist by means of kneading, patting, kneading and patting mainly, apply air massage on the legs and feet for squeezing massage, allowing more soothing leg and foot massage, suitable for sedentary people with low stress on the legs and feet, not only relieving the cervical spine, lumbar spine pain of sedentary people, but also soothing the legs and feet. Massage intensity is gentle.

Massage scenes(Relaxing and Activating)	
Function	Description
Energy	Massage the waist, shoulders and neck by means of kneading, patting, kneading and patting techniques, to awaken the body's vital energy, stimulate physical energy through such deep massage of the whole body with the massage intensity being heavy, which is suitable for people with strong stress, such as athletes, for stimulating the potential before a race.
Lunch Break	Massage the back and waist by means of kneading and patting techniques, and press the Shenyu acupoint, to improve the quality of lunch break, so that the user is more energetic in afternoon work. It is suitable for office workers, and the massage intensity is gentle.
Sweet Dream	Massage the shoulders, neck, back and waist by means of kneading and medical massage techniques, and press the acupoints of Fengchi and Shenyu, to improve the sleep quality and help sleep. It is suitable for people suffering from poor sleep, and the massage intensity is gentle.

Operation Instructions

Relieve Muscle	Mainly massage the back and waist with flapping and kneading techniques to promote blood circulation and eliminate local muscle soreness. Suitable for people with long-term weight-bearing activities and muscle strain. The massage intensity is moderate.
Body Balance	Mainly massage the shoulders & neck, back & waist with kneading, 4D kneading and shiatsu. Suitable for people who are mentally stressed, physically and mentally unbalanced. The massage intensity is gentle.

Massage scenes(Exclusive for Family)	
Function	Description
President Cosy	Massage the shoulders, neck, back and waist by means of kneading, patting, kneading and patting mainly, to relieve fatigue, promote blood circulation, and release stress by such deep massage. It is suitable for men, and the massage intensity is moderate.
Keep Fit	Massage the shoulders, neck, waist and hips by means of kneading and finger pressing techniques, through the massage on the whole body, to relax the body and mind, and enjoy the queen-level treatment. It is suitable for women, and the massage intensity is gentle.
Superior Enjoyable	Apply air massage on the whole body, with the foot roller and calf kneading massage. Calf stretching function is canceled, suitable for the elderly and people suffering stress on back. The massage intensity is gentle.
Office Regimen	Massage the shoulders, neck and waist by means of kneading, patting, kneading and patting techniques mainly, to relieve shoulder and neck pain, improve lumbar muscle soreness and maintain lumbar spine through such deep massage. It is suitable for office white-collar and sedentary people, and the massage intensity is moderate.


Operation Instructions

Health Recharge	Deeply massage the whole body by means of kneading, patting and finger pressing techniques, to promote blood circulation throughout the body and prevent blood clots. It is suitable for people who live at home for a long time and do not like to go out, and the massage intensity is moderately gentle.
-----------------	---


Massage scenes(Overall Relaxation)	
Function	Description
Yoga massage	The legs, hands and shoulders are mainly clamped by air pressure, and the massage chair automatically adjusts various angles to achieve the effect of stretching and traction. Suitable for people who practice yoga. The massage intensity is moderate.
Chinese Massage	By means of Traditional Chinese medicine massage technique mainly, apply 3D massage on the back and waist so as to promote the blood circulation of the back and waist, soothe the meridians and relieve the blockage of the back and waist through massage. It is suitable for people with back and waist pain, and lumbar muscle strain. Massage intensity is gentle.
Full-body stretch	Stretch your legs and waist through the legrest and the backrest to effectively remove fatigue, relieve joint pain and restore vitality.
Spine Traction	Mainly use the calf, backrest electric push rod and air pressure to clamp the human body's legs, hands and shoulders, and then pull the spine to different angles. Can improve the deformation and curvature of the spine. Strong massage.
Spine Massage	Improve humpback and chest down; massage for each vertebra; care for the spine health; and improve the protrusion of intervertebral disc.

Operation Instructions

2. More programs: Enter the automatic mode interface as shown below, select the "More Programs" **More Massage** key, then click the "+" key to select the "Undownloaded Programs" key in the pop-up window, and then select the corresponding automatic massage program according to the massage needs. Then click the "Download" key to download after selecting. Click the "Back" key to exit the download interface. Note: This function can only be used when the WIFI connection is successful. If the WIFI network is not connected or the connection is not successful, the online program will not be displayed on the interface.



3. After the download is successful, you can select this function for massage in more program interfaces; such as Yoga meditation, Organ conditioning, Classical Comfort, Yangzhou back rubbing, etc. Note: More programs are automatically recommended by the system, and the automatic name is not unique. .




Operation Instructions

IV.Remote program (please use this function after the equipment is turned on)

1.After pressing the "Manual" key in the menu bar on the left side of the controller screen to enter the manual menu, you can select manual massage functions such as "Technique adjustment, Air pressure massage" according to massage needs.

(1).Technique adjustment: After entering the manual menu interface as shown below, select the "Manual"key, then select the massage functions according to the massage needs, including massage technique, massage area, 4D intensity, back mechanism adjustment, massage width, massage speed massage functions.

1).Massage techniques: There are a total of 17 massage techniques available, including no technique, knead (with 7 modes of cyclic switching), tap I, tap II, knead & tap, shiatsu I, shiatsu II, grasp, 4D I, 4D II, 4D III and 4D IV. (Note: Click on the"left arrow <" and right arrow >" key in the technique adjustment menu can scroll left and right to display and switch more massage techniques.)




Manual mode–Manual diagram

Function	Message roller adjustment	
Stop	The width, intensity and be adjusted.	Adjustable speed in five gears
Knead	The speed, intensity and be adjusted.	
Tap I	The speed, width, intensity and be adjusted.	
Tap II	The speed, width, intensity and be adjusted.	
Knead&Tap	The speed, intensity and be adjusted.	
Shiatsu I	The speed, width, intensity and be adjusted.	Adjustable width in five gears
Shiatsu II	The speed, width, intensity and be adjusted.	
Grasp	The speed, intensity and be adjusted.	Adjustable intensity in five gears
4D I	The speed, intensity and be adjusted.	
4D II	The speed, intensity and be adjusted.	
4D III	The speed, width, intensity and be adjusted.	
4D IV	The speed, width, intensity and be adjusted.	


Operation Instructions

Note: In the "Home" interface, you can also click the massage technique key, to select the corresponding massage technique in the pop-up menu for massage (this function is a shortcut for switching massage techniques in the current status page of the remote program - technique adjustment).








Current Status -Technique Selection Diagram

2.Message area: After entering the manual menu interface as shown in the figure below, select the "Technique Adjustment" key, and then select the corresponding massage area function for massage according to the massage needs. There are five massage areas available: spot, partial, full back, upper back and lower back. Select the corresponding massage area from the massage area menu to start the massage.




Manual Mode -Massage Area Selection Diagram

Operation Instructions

Key	Description
	Fixed-point massage at fixed-point position.
	Small-scope local massage back and forth.
	Full back massage back and forth.
	Upper back massage back and forth.
	Lower back massage back and forth.


Note: In the "Home" interface, you can also click the massage area key **Area**, to select the corresponding massage area in the pop-up menu for massage (this function is a shortcut for switching massage areas in the current status page of the remote program - massage area).




Current Status -Massage Area Diagram



Operation Instructions

3.4D intensity: After entering the manual menu interface as shown in the figure below, select the "Manual Adjustment **Manual**" key, and then select the 4D intensity plus "**+**" key or minus key "**-**" according to the massage needs to adjust the 4D intensity; The 4D intensity can be adjusted in a total of 1-5 levels, with 1 level indicating the weakest intensity and 5 levels indicating the strongest intensity. The stronger the 4D intensity, the higher the pushing out of the massage wheel, and the greater the massage intensity.




Manual Mode - 4D Intensity Diagram




Key	Description
	Press it to increase 4D intensity which is adjustable from 1 to 5.
	Press it to decrease 4D intensity which is adjustable from 1 to 5.

Operation Instructions

Note: In the "Home" interface, you can also select the 4D intensity + **4D +** key or 4D intensity - **4D -** key to adjust the 4D intensity. This function is a shortcut to the 4D intensity in the current status page of the remote program-4D intensity.




Current Status - 4D Intensity Diagram



Key	Description
4D +	Press it to increase 4D intensity which is adjustable from 1 to 5.
4D -	Press it to decrease 4D intensity which is adjustable from 1 to 5.

Operation Instructions


4. Back mechanism up and down adjustment: After entering the manual menu interface as shown in the figure below, select the "Technique Adjustment **Manual**" key, and then select the "up arrow" or "down arrow" of the back mechanism according to the massage needs to adjust the back mechanism up and down. The adjustment of the back mechanism needs to be used in the spot and partial massage area of manual mode.



Manual Mode - Diagram of the back mechanism Adjustment


5. Message width: After entering the manual menu interface as shown in the figure below, select the "Technique adjustment **Manual**" key, and then select the message width plus key "**+**" or minus key "**-**" according to the massage needs to adjust the message width. There are 1 to 5 levels of width to choose from, with 1 level being the narrowest and 5 levels being the widest; Width adjustment needs to be used in the following massage techniques: Stop, Tap I, Tap II, Shiatsu I, Shiatsu II, 4D III, 4D IV.

1). Users must enter manual mode after selecting massage technique or massage area before adjusting the width.



Manual Mode - Message Width Adjustment Diagram


Operation Instructions



Key	Description
	Press it to increase message width which is adjustable from 1 to 5.
	Press it to decrease message width which is adjustable from 1 to 5.


6. Message speed: After entering the manual menu interface as shown below, select the "Technique adjustment **Manual**" key, and then select the message speed plus key or minus key according to the message needs to adjust the message speed. There are 1-5 levels message speeds available, with 1 level being the slowest and 5 level being the fastest, Message speed needs to be used in the following message techniques: Knead, Tap I, Tap II, Knead&Tap, Shiatsu I, Shiatsu II, Grasp, 4D I, 4D II, 4D III, 4D IV

(1).Users must enter manual mode after selecting the massage technique or massage area before adjusting the speed.




Manual Mode - Massage Speed Adjustment Diagram

Operation Instructions




Key	Description
	Press it to increase message speed which is adjustable from 1 to 5.
	Press it to decrease message speed which is adjustable from 1 to 5.



Note: In the "Home

 interface, you can also select the message speed + key or message speed - key to adjust the message speed.


Current Status - Massage Speed Diagram







Operation Instructions

Key	Description
	Press it to increase massage speed which is adjustable from 1 to 5.
	Press it to decrease massage speed which is adjustable from 1 to 5.


7. Air pressure massage : After entering the manual menu interface as shown below, select the "Air pressure massage" key, the air pressure massage includes full body pressure, upper body pressure, and lower body pressure and air pressure intensity massage.



(1). After entering the air pressure massage interface as shown below, select the "full body, upper body or lower body" key to turn on or off the air pressure function according to the massage needs. If all is turned off, all air pressure functions will be turned off.




Key	Description
	Press it to enable or disable the whole body air massage function.
	Press it to enable or disable the upper body air massage function.
	Press it to enable or disable the lower body air massage function.

Operation Instructions





Note: In the "Home"  interface, you press also air massage  key and select corresponding air mode in the pop-up menu. (This function is a shortcut to the air massage in the current status interface of the remote function - air massage.)



Current status - Schematic diagram of air massage

Operation Instructions


8. Air pressure intensity: After entering the manual menu interface as shown in the figure below, select the "Air pressure massage" **Air** key, activate the air pressure massage function for different parts according to the massage needs, and then select the upper body air pressure increase key **+** or upper body air pressure decrease key **-** to adjust the upper body air pressure intensity; You can also choose to increase the lower body air pressure by pressing the **+** key or decrease the lower body air pressure by pressing the **-** key to adjust the intensity of the lower body air pressure; The air pressure intensity can be adjusted in 1-5 levels, with 1 level indicating the weakest intensity and 5 levels indicating the strongest intensity.




Key	Description
+	Press it to increase the air intensity which is adjustable from 1 to 5.
-	Press it to decrease the air intensity which is adjustable from 1 to 5.

Operation Instructions

Note: In the "Home" interface, you can select the upper body air pressure **Upper Air+** key or the upper body air pressure **Upper Air-** key to adjust the upper body air pressure intensity; can also select the lower body air pressure **Lower Air+** key or the lower body air pressure **Lower Air-** key to adjust the lower body air pressure intensity, the air pressure intensity is divided into 5 levels.



Home - Schematic diagram of air pressure intensity




Key	Description
Upper Air + Lower Air +	Press it to increase the air intensity which is adjustable from 1 to 5.
Lower Air - Upper Air -	Press it to decrease the air intensity which is adjustable from 1 to 5.

Operation Instructions



V. Seat adjustment

Select and click the "Angel" key in the menu bar on the left side of the remote controller screen, after entering the sitting adjustment interface as shown below. According to the massage needs, select the sitting angle adjustment, including Foot shorten, Foot extend, Leg up, Leg down, Whole up, Whole down, Back down, zero gravity I, zero gravity II.





Schematic diagram of sitting posture adjustment

1.Zero-gravity adjustment



Key	Description
 Zero I	Zero-gravity 1 key: automatically adjust the position of leg unit and backrest unit to zero-gravity 1 position.
 Zero II	Zero-gravity II key: automatically adjust the position of leg unit and backrest unit to zero-gravity II position.

2.Telescopic adjustment of footrest



Key	Description
 Foot shorten	Footrest shortening button: Manually adjust the footrest to shorten; press and hold it to move the footrest slowly upward, and release it to stop. the adjustment will stop and a "drip" sound will be heard when the adjustment reaches the limit position.
 Foot extend	Footrest extension key: Manually adjust the extension of the footrest; press and hold it to move the footrest slowly downward, and release it to stop. the adjustment will stop and a "drip" sound will be heard when the adjustment reaches the limit position.

Operation Instructions



3.Leg unit extension/shortening adjustment

Key	Description
 Leg up	Leg unit Up key: press and hold it to slowly raise the leg unit, and release it to stop rising; after the leg unit rising action is completed, the adjustment will stop and a "drip" sound will be heard when the adjustment reaches the limit position. the leg unit will automatically detect the foot length.
 Leg down	Leg unit Down key: press and hold it to slowly lower the leg unit, and release it to stop lowering; after the leg unit lowering action is completed, the adjustment will stop and a "drip" sound will be heard when the adjustment reaches the limit position. the leg unit will automatically detect the foot length.

4.Backrest unit angular adjustment

Key	Description
 Back up	Backrest unit Up key: press and hold it to slowly raise the backrest unit and release it to stop rising. the adjustment will stop and a "drip" sound will be heard when the adjustment reaches the limit position.
 Back down	Backrest unit Down key: press and hold it to slowly lower the backrest unit and release it to stop lowering. the adjustment will stop and a "drip" sound will be heard when the adjustment reaches the limit position.

5.Linkage lifting Angle adjustment


Key	Description
 Whole up	Linkage Up key: press and hold it to slowly raise the backrest unit while slowly lowering the leg unit, and release it to stop raising the backrest unit or lowering the leg unit; after the linkage rising action is completed, the adjustment will stop and a "drip" sound will be heard when the adjustment reaches the limit position. the leg unit will automatically detect the body height.
 Whole down	Linkage Down key: press and hold it to slowly lower the backrest unit while slowly raising the leg unit, and release it to stop lowering the backrest unit or raising the leg unit; after the linkage lowering action is completed, the adjustment will stop and a "drip" sound will be heard when the adjustment reaches the limit position. the leg unit will automatically detect the body height.

Operation Instructions

VI. Setting (please use this function after the equipment is turned on)

Click the "Settings" key in the menu bar on the left side of the remote controller screen to enter the setting interface, after entering the sitting adjustment interface as shown below can view the product number, software version number, ID code and firmware version number. Also can perform system settings in the interface, including Bluetooth, screen brightness, language selection, LED, screen shutdown, voice control, key tone, network connection system setting functions.

- 1.Voice Control: Click Voice Control switch to enable or disable the Voice Control function. After enabling the voice function, you can control the massage chair by voice according to the content of the voice entry.



Schematic diagram of Setting

- (1).In the massage chair open state, you can short press the "Voice control key" to wake up the voice assistant feature (If unable to wake up, please enter the setting interface to check whether the voice control switch is on or not, if not, please turn on the voice control switch).or you can near the left armrest position to say "Hi Alice" or "Hey Alice" to wake up the voice assistant, when the voice assistant replies "I'm here", it represents that it has been woken up, and after opening the voice control assistant, you can use the voice control assistant function to control the massage chair.
- (2).You can also short press the "Voice key" button in the armrest shortcut key to wake up the voice assistant, and long press and hold this key for 3 seconds to turn it on or off.
- (3).After the voice assistant wakes up, please say the command within 6 seconds to realize the function control of the Massage chair. After the voice assistant responds to the command, you can continue to say the command. The interval between two adjacent commands cannot exceed 6 seconds, otherwise you need to wake up the voice assistant again. The detailed voice command table is as follows:

Attention: When awakening the voice control function, the speaking speed should not be too fast, and voice commands should be issued according to Voice Control Entry.

Operation Instructions

Voice Control Entry		
Entry: "Hi Alice" or "Hey Alice". Answer: I am here.		
No.	Voice control entry	Answer entry
1	Massage on	Answer: Ok, Massage on
2	Massage close	Answer: Ok, Massage close
3	Total Relax	Answer: Ok, Total Relax
4	Energy Boost	Answer: Ok, Energy Boost
5	Sweet Dream	Answer: Ok, Sweet Dream
6	Neck & Shoulder Care	Answer: Ok, Neck & Shoulder Care
7	Lunch Break	Answer: Ok, Lunch Break
8	Thai Massage	Answer: Ok, Thai Massage
9	Open the air pressure	Answer: Ok, Open the air pressure
10	Close the air pressure	Answer: Ok, Close the air pressure
11	Up the seat position	Answer: Ok, Up the seat position
12	Down the seat position	Answer: Ok, Down the seat position
13	Change the other mode	Answer: Ok, Change the other mode
14	Go little down	Answer: Ok, Go little down
15	Go little up	Answer: Ok, Go little up


Note: commands 14 and 15 can only be used after command 13.

2. Bluetooth(Operation Instructions for Bluetooth Speaker Play)


- (1).Bluetooth: After entering the setting interface as shown below,click the "Bluetooth" switch to turn on or off the Bluetooth function.After the Bluetooth function is turned on, the audio source device with Bluetooth function (such as mobile phone, MID tablet, etc.) can be paired and connected with the Bluetooth module of the massage chair, and the music played by the audio source device can be transmitted wirelessly to the massage chair sound system through Bluetooth for music playback.
- (2).Enter the smart device main menu. Open "Settings" and select the "Bluetooth" option. Open "Bluetooth", and Bluetooth will automatically "Search for a New Bluetooth Device".

Operation Instructions

- (3).The smart device will search for the corresponding Bluetooth model (e.g. IMCM-XXXX). Click the "Match" button. If you are asked whether to match with the device, you just select "Match" to complete matching.
- (4).Turn on "Music Player" in the smart device and select the song to play.




- 3.LED: After entering the setting interface as shown below, click the "LED" key to turn on or off the ambient light function.




Operation Instructions

- 4.Key tone: After entering the setting interface as shown below, click the "Key tone" key, and then turn on or off the key tone function according to the message needs. After the key tone function is turned on, a sound will be emitted when the remote controller key is clicked; if it is turned off, there will be no key sound.




- 5.Screen brightness: After entering the setting interface as shown below, click the "Brightness" slider, and then press and hold to slide left and right to adjust the brightness of the hand controller screen according to the message needs.




Operation Instructions

6. Screen shutdown: After entering the setting interface as shown below, click the "Shutdown" key, and then select the screen shutdown time in the drop-down pop-up window according to the message needs. There are 6 screen shutdown time options available, including 15 seconds, 1 minute, 5 minutes, 10 minutes, 20 minutes, and never screen shutdown.




7. Language selection: After entering the setting interface as shown below, select different languages according to the user's needs. The default language is English and Chinese can be selected.




Operation Instructions

8. Network connection: After entering the setting interface as shown below, select the "Click to connect to the network" key, the system will jump directly to the smart device WIFI networking interface, and then select the corresponding network name according to the needs to connect the device. After the connection is successful, the WIFI icon will be highlighted. Note: If there are new versions of the firmware and software versions, can click to update.




9. Version upgrade: After entering the setting interface as shown below, if you find that the version needs to be upgraded, select the text "Discover new version, click to upgrade" after "Firmware version or software version" according to the system requirements to upgrade the system version. During the version upgrade process, "Keep the message chair powered and do not operate the message chair at will." Note: Please refer to the upgraded version for the version number.




Operation Instructions

VII. Health detection (please use this function after the equipment is turned on)

1. Health detect starts: Click the "Health" button in the menu bar on the left side of the display screen to enter the health detection interface, press the start button to perform health detection, and then gently place the index finger or middle finger on the sensor. After a few seconds, it will display the real-time data of heart rate, blood oxygen and microcirculation, waiting for the completion of the detection progress.




Health check progress indicator




Operation Instructions

2. Recommended program: When normal detection is completed, it will display the heart rate, blood oxygen, and the fatigue level, respectively. The blood oxygen means with the blood oxygen concentration ranging from 95% to 99% normally. The fatigue levels include Good, Mild, Moderate and Severe. Based on your fatigue level, an automatic program will be recommended for you. Select "Yes" to start using the recommended program and "No" to return to the massage state before the health detection.




3. No valid data is detected: If no valid data is detected, the user will be prompted to ask whether to re-detect. Select "Yes" to restart the health detection, and "No" to exit the detection and return to the massage state before the health detection.




Operation Instructions

4.Exit health detection: During health detection, press the **Exit** key to exit the detection and return to the massage state before the health detection.



VIII. Custom (please use this function after the equipment is turned on)


Click the "Custom" key in the menu bar on the left side of the display to enter the custom setting interface and select either Custom I or Custom II (only if the corresponding custom has been previously set and saved) for massage.



Schematic diagram of Custom


Operation Instructions

Click Custom I Setting or Custom II Setting to enter the Custom Setting interface, then select the preferred massage technique whose icon will be highlighted after selection, and select the massage interval, 4D intensity, air massage, massage width, massage speed, air intensity, back heating, calf kneading and other functions, then click Save to save the current settings as Custom I and Custom II. After the settings are saved successfully, the custom program will be immediately available and can be used for the next massage by clicking the saved custom program.





IX.Storage (please use this function after the equipment is turned on)

Click the "Memory" key in the menu bar on the left side of the display to enter the massage function storage selection interface, with two categories including message function storage and message function call. Message storage includes: Save I, Save II and Save III. Message call includes: Use I, Use II and Use III




Operation Instructions

Key	Description
	Storage: Saving the currently running massage program, including automatic program, massage technique, air mode and intensity, position and angle of leg unit and backrest unit, and other massage functions.
	Call: Calling the previously saved massage program, including automatic program, massage technique, air mode and intensity, position and angle of leg unit and backrest unit, and other massage functions.


X. Other function (Please use this function after power on)

1.Back heating: As shown in the following figure, in the "Home" interface, click the "Back heat" button to turn on or off the back heating function, and it will warm after 3 minutes of turning on the heating function.




Operation Instructions

2.O₂-lon: As shown in the following figure, In the "Home" interface, select the "O₂-lon" button to turn on or off the O₂-lon function.




3.Foot Rollers: As shown in the following figure, In the "Home" interface, click the "Roller" button to turn on or off the foot roller massage function, with three adjustable speeds. Press it for the first time to start Level 1 speed; press it for the second time to start the Level 2 speed; press it for the third time to start the Level 3 speed; and press it for the fourth time to disable the Sole Roller function, which are switched cyclically.




Operation Instructions

4. Calf: As shown in the following figure, In the "Home" interface, click the "Calf" button to turn on or off the calf kneading massage function; there are kneading and airbag squeezing massage functions on the inside and outside of the calf, which can relieve the stiffness or tension of the calf muscles caused by standing for a long time.




5. Voice: As shown in the following figure, In the "Home" interface, click the "Voice" button to wake up the voice assistant. If you press this button and emit a "drip, drip" sound, the voice assistant cannot wake up normally, please go to the setting screen to confirm whether the voice control function is enabled. If the voice control function is not enabled, please turn it on.




Operation Instructions

6. Shoulder adjustment: As shown in the following figure, In addition to setting in the Custom interface, the function can also be enabled or disabled by selecting the In the "Home" interface, select the "Shoulder Position Adjustment" button, and press the up and down arrow buttons in the pop-up menu to adjust the shoulder position, with a total of 11 adjustable levels.




7. Massage time adjustment: In addition to setting in the Custom interface, the function can also be enabled or disabled by selecting the In the "Home" interface, select the "massage time adjustment 00:30" button, press the plus and minus arrow head button in the pop-up menu, you can increase or decrease the massage time. Click the "+" key, the time increased by 5 minutes, the maximum increase to 40 minutes. Click the "-" key, the time decreased by 5 minutes.



Operation Instructions

7. Select level: As shown in the following figure, In addition to setting in the Custom interface, the function can also be enabled or disabled by selecting the In the "Home" interface, select the "Gentle Strong", Soothing Gentle, Strong Soothing" button to select the appropriate massage intensity.



This is the end of massage chair remote controller operation instructions.

Operation Instructions

XI. Bluetooth App Download and Install

1. Bluetooth APP download and install:

- (1). Android (Android system) download method: Search "Alfine" in Google Play (Google Store) to download and install the Android version, or scan the QR code below to download and install. After successful installation, you can use the Bluetooth APP to operate the massage chair.
- (2). Apple (iOS system) download method: Search "Alfine" in the App Store (Apple App Store) to download and install the Android version, or scan the QR code below to download and install. After successful installation, you can use the Bluetooth APP to operate the massage chair.




Alfine




2. APP Bluetooth search connection: After the APP is successfully installed, click the "Alfine" icon in the smart device interface. After opening the Alfine APP, it will automatically jump to the Bluetooth connection interface. At the same time, the APP will automatically search for the corresponding device Bluetooth number (such as IMCM -XXXX), then click on the corresponding device Bluetooth number (and displays connected), then the connection is successful. After the connection is successful, you can operate the massage chair through the APP. Note: The Bluetooth function and location information of the smart device system must be turned on before the device is connected.

- (1). At the same time, different languages can also be selected according to the user's massage needs. The default language is English and Chinese can be selected.




Operation Instructions

3.APP Bluetooth name change: If the location of the massage chair is changed or the Bluetooth name is changed, you need to reconnect the device according to the actual situation; after entering the APP interface as shown below, select and click the "Setting" key in the left menu bar, and then select "Device connection" key to connect the device. Note: The Bluetooth function and location information of the smart device system must be turned on before the device is connected.




(1).After entering the setting interface as shown below, select and click the "Device connection" key. In the pop-up window interface, the APP will automatically search for the corresponding device Bluetooth number (such as IMCM-XXXX), and then click to select the corresponding device Bluetooth number (and displays connected), then the connection is successful. After the device is successfully connected, the massage chair can be operated.




Operation Instructions

XII. APP controlled message chair operation instructions

1.After the device is successfully connected, the Bluetooth APP will automatically jump to the standby interface. As shown in the figure below, click the "Switch" key in the menu bar in the lower left corner to turn on the massage function.






2.After turning it on, you can enter the main interface and select the corresponding message function according to your needs.




Caution For the massage chair Bluetooth APP interface operation method, you can refer to the touch screen remote controller interface operation method of this manual.


Operation Instructions

XIII.End massage


During the massage process, press the "Switch  " key on the remote controller or press the "Switch  " key on the armrest to turn it off. You can also press the "Switch  " key on the Bluetooth APP interface to immediately turn off all massage functions and reset the backrest mechanism and leg mechanism, or when the massage time is up, the massage chair will automatically turn off all massage functions and the backrest and leg mechanism will not reset.




Cut off the whole machine power supply, as shown in the figure (Schematic diagram of power switch position of the whole machine).



Turn off the power switch ("0" position)



Schematic diagram of pulling out the power plug




Remove the product connection power cord

Cleaning and Maintenance

Cleaning synthetic leather and plastic parts

Wipe the leather with a soft, dry cloth.

- Do not use chemicals such as thinner, gasoline, alcohol, etc. to clean the unit.
- When using commercially available leather care products (rags), please follow the instructions for use.
- If synthetic leather is particularly dirty, wipe it in the following way.
 - ① Immerse a soft cloth in water or hot water containing 3% to 5% neutral detergent, then wring it out thoroughly.
 - ② Use the above soft cloth to wipe the leather surface.
 - ③ Wipe off the cleaning solution with a cloth soaked in clean water and thoroughly wrung out.
 - ④ Wipe with a wrung soft cloth.
 - ⑤ Let it air dry naturally.
- When it is difficult to remove stains, please immerse commercially available melamine foam in neutral detergent, and then wipe the machine with it.
- Do not use a hair dryer to dry the surface.
- Be careful when wiping the machine with denim and colored fabrics, as the color of the fabric will stain the surface of the synthetic leather.
- Do not keep these parts in contact with plastic for a long time, as this will cause discoloration.
- Synthetic leather may be discolored, so when using hair dye, please cover the touched part with a towel.



Troubleshooting

Fault	When the calf mechanism or the backrest reaches a certain position, press the corresponding adjustment button and it will no longer change, and a continuous "beep, beep" sound will be emitted.
Solution	Due to product structure design and ergonomic requirements, this product has a limited protection design for the limit state of attitude adjustment. At the same time, a reminder sound will sound when the limit is reached.

Fault	The function does not work or some functions do not work after the machine is turned on.
Solution	After the machine is turned on by pressing the switch key, it is necessary to manually select an automatic massage program or other working state. If it is not operated, the machine will automatically shut down after 20 minutes. If the manual operation mode is selected, the functions that are not selected may be disabled, and the working mode needs to be manually set in the manual mode.

Fault	The machine makes a leather rubbing sound when adjusting its posture.
Solution	This product adopts high-grade anti-corrosion leather that meets environmental protection requirements. Due to the inherent characteristics of leather materials, there will be a normal slight noise when rubbing at the relative movement, which is a normal phenomenon. Note: If you hear fabric or leather tearing sound when the machine is running, please stop using it immediately and seek professional maintenance.

Fault	The massage wheel did not reach the shoulders or neck.
Solution	If the head does not touch the head cushion or the back does not touch the backrest, the shoulder position may be lower than the actual position during the body shape detection process. Sit in the deepest position of the seat, rest your head on the headrest, and start over from the beginning.

Fault	The unit is damaged. The power cord or power plug is abnormally hot.
Solution	To prevent accidents, be sure to contact an authorized service center.

Please feel free to contact the designated service personnel for any questions or doubts about this product.

Product specifications

Model: A710
Configure: 26
Name: Massage Chair
Rated voltage: 110-120V~ 60Hz
220-240V~ 50Hz/60Hz
Rated power: 220W
Rated time: 20min
Safety structure: Class I